Acquiring RAID Disks (Cont'd)



Identifying RAID Drives in Linux system

Command to check whether RAID is configured:

lspci | grep RAID

Command to obtain essential information about active RAID devices:

cat /etc/mdadm.conf

Command to check the current status of RAID devices:

cat /proc/mdstat

Command to examine the details of the RAID device:

mdadm --detail /dev/md125

Rebuilding RAID

SalvageData Total Recovery Pro It is a RAID recovery tool that can help investigators to recover deleted or lost files from hard drives or external storage devices




Step 7: Plan for Contingency



Investigators must be prepared for contingencies such as when the hardware or software does not work or failure occurs during acquisition


Hard Disk Data Acquisition

- Create at least two images of the digital evidence collected
- If one copy of the digital evidence recovered becomes corrupt, investigators can then use the other copy



Imaging Tools

- Use two or more imaging tools such as FTK Imager and ProDiscover Pro to create two images of the evidence
- If the investigator has access to only one tool, create two or more images of the drive using the same tool



Step 7: Plan for Contingency (Cont'd)



Hardware Acquisition Tools

 Use hardware acquisition tools such as UFED Ultimate or IM Solo-4 PLUS IT Enterprise that can access the drive at the BIOS level to copy data in the Host Protected Area (HPA)



Drive Decryption

- Investigators must be prepared to deal with encrypted drives that require decryption keys from users
- Microsoft Windows has a full disk encryption feature such as BitLocker in some selected versions



Step 8: Validate Data Acquisition



Validating data acquisition involves calculating the hash value of the target media and comparing it with its forensic counterpart to ensure that the data have been completely acquired



Hash value calculation generates a unique numeric value for files, often considered as "digital footprint," which represents the uniqueness of a file or disk drive



Some hashing algorithms that can be used to validate the data acquired include CRC-32, MD5, SHA-1, SHA-3, SHA-256, SHA-512, and BLAKE2



Acquiring RAID Disks



Forensic examiners may encounter challenges when acquiring data from RAID disks, primarily owing to the intricate design, complex configurations, and considerable storage capacities associated with RAID systems

Consider the following factors before acquiring data:

- The amount of data storage required to acquire all data
- The RAID format used (RAID 0, RAID 1, RAID 5, RAID 10, etc.)
- Check whether RAID is managed by hardware or software
- Forensic tools suitable for imaging RAID disks and reading these images

- Decide whether to perform disk imaging (bit-by-bit) or logical acquisition (file-level) based on the RAID configuration
- Ensure that the forensic hardware and software tools are compatible with the RAID controller in use
- Reconstruct the RAID array on a separate forensic workstation or by using specialized RAID recovery tools
- Calculate and compare checksums of the acquired data with the original RAID array to verify data integrity
- Several computer forensics tools such as OpenText EnCase Forensic, X-Ways Forensics, and ProDiscover are built with capabilities to recover RAID disks

Step 8: Validate Data Acquisition – Windows Validation Methods



The Get-FileHash cmdlet computes the hash value for an evidence file using the specified hash algorithm

- This hash value is used throughout the investigation for validating the integrity of the evidence
- Investigators can also use commercial computer forensic programs such as ProDiscover, which have built-in validation features that can be used to validate evidence files

```
Administrator: Windows PowerShell

PS C:\Users\Admin\Desktop\dd> Get-FileHash 'Z:\Evidence\Windows_Evidence_001.dd' -Algorithm MOS | Format-list

Algorithm : MOS

Hash : ABAE472D13F9793D58DAB808554D82AE

Path : Z:\Evidence\Windows_Evidence_001.dd

PS C:\Users\Admin\Desktop\dd>

PS C:\Users\Admin\Desktop\dd>
```

Step 8: Validate Data Acquisition – Linux/Mac Validation Methods



Validating Data Acquired with dd

- Run the following command to acquire an image in a single file:
 - dd if=/dev/sda of=/image_sda.dd
- Now, you can use the md5sum utility to validate the image
- Run the following command to calculate the hash of the original drive: md5sum /dev/sda > md5_hashes.txt
- Run the command cat image_sda.dd | md5sum << md5_hashes.txt to calculate the MD5 hash for the image file and generate the output to the md5 hashes.txt file



Validating dcfldd Acquired Data

- Enter the following command in the terminal to create an image and calculate sha256 hash post-data acquisition:
 - dcfldd if=/dev/sda split=100M
 of=/media/image.dd hash=sha256
- Run the following command in the terminal to create an image and store its sha256 hash value in a text file:
 - dcfldd if=/dev/sda split=100M
 of=/media/image.dd hash=sha256
 hashlog=/media/sha256.txt
- Navigate to the directory and enter the 1s command to view the files generated

```
root@jason-Virtual-Machine:/home/jason/Documents
root@jason-Virtual-Machine:/home/jason/Documents# [is
image2.dd image.dd.002 image.dd.005 image.dd.008
image.dd.000 image.dd.003 image.dd.006 image.dd.009
image.dd.001 image.dd.004 image.dd.007 sha256.txt
root@jason-Virtual-Machine:/home/jason/Documents#
```

Data Acquisition Guidelines and Best Practices



1	Define the purpose and data requirements of data	П
1	acquisition	ш

Minimize data duplication and examine the sensitivity of fresh datasets

2 Identify data sources to obtain evidence

Comply with legal and ethical data protection laws and regulations

Devise a suitable data acquisition strategy

9 Document the entire data acquisition process

Select appropriate data acquisition tools considering the requirements

Establish access controls, read-only mode, and encryption techniques to maintain data security

Gather only relevant data to mitigate the risk of violating an individual's privacy rights

Use the data for their original purpose only and avoid misinterpretation

Capture volatile evidence first and then proceed to non-volatile data Evaluate the quality and efficiency of the adopted data collection plan regularly

LO#04: Prepare an Image File for Examination

- Preparing an Image for Examination
- Scenario 1: Examining Images on Linux Forensic Workstation
- Scenario 2: Examining Images on Windows Forensic Workstation
- Scenario 3: Examining Images on Mac Forensic Workstation
- Digital Forensic Imaging Tools

Preparing an Image for Examination



After collecting image files, the investigator should ensure that the image files are ready for examination


Investigators might encounter challenging situations when the file format of the acquired image file is incompatible with the OS used in the forensic workstation

An investigator might encounter the following scenarios during investigation:

Scenario 1: Examining Images on Linux Forensic Workstation

Scenario 2: Examining Images on Windows Forensic Workstation

Scenario 3: Examining Images on Mac Forensic Workstation







Scenario 1: Examining Images on Linux Forensic Workstation



Linux workstations support many file systems and contain advanced tools for conducting forensic investigations

- An investigator might encounter the following scenarios during investigation on a Linux forensic workstation:
 - Scenario 1.1: Converting E01 image file to dd image file
 - Scenario 1.2: Converting E01 image file to raw image file
 - Scenario 1.3: Converting dd image file to VHDX file
 - Scenario 1.4: Examining a dd image file
 - Scenario 1.5: Examining physical hard disk
 - Scenario 1.6: Examining Mac APFS image file
 - Scenario 1.7: Examining disk image using PyTSK
 - Scenario 1.8: Examining EWF-formatted disk image using libewf
 - Scenario 1.9: Examining disk image using dfvfs library



Scenario 1.1: Converting E01 Image File to dd Image File



- When an investigator is presented with an E01 file, they cannot directly examine it on a Linux workstation
- The E01 file must be converted to the dd file format using "xmount" to access the mounted volume's files or directory structure

To Convert E01 to dd on Linux

Use the xmount command to convert the E01 image to dd image

Command:

```
xmount --in [input_image_format]
[file name.E01] [mount directory]
```

The converted image file can be viewed in the xmount directory, as shown in the screenshot

E01 file is converted to dd image file

Scenario 1.2: Converting E01 Image File to Raw Image File



The E01 file must be converted to raw image file format using "ewfmount" to access the mounted volume's files or directory structure

Generate Raw Image Using "ewfmount"

Use ewfmount command to generate raw image from E01 image file

Command:

```
ewfmount [file_name.E01]
[mount_directory]
```

Mount Raw Image Using "mount" command

Use mount command to mount the image file

```
Command: mount [raw_image_filename] [mount_directory] -o ro, loop, show sys files, streams interface=windows
```

```
roots]ason-Virtual-Machine:/mot/ewfmount# nkdir /mount
roots]ason-Virtual-Machine:/mot/ewfmount# mount ewf1 /Mount/ -o ro.loop.show_sys_files
streams_interface-windows
roots]ason-Virtual-Machine:/mot/ewfmount# cd /mount
roots]ason-Virtual-Machine:/mount# ls -la
total 6448
drwxrwxrwx 1 root root 4096 Dec 19 2019
drwxrwxrwx 1 root root 4096 Dec 19 2019
drwxrwxrwx 1 root root 4096 Dec 19 2019
drwxrwxrwx 1 root root 60 Dec 19 2019
-rwxrwxrwx 1 root root 60 Dec 19 2019
```

Scenario 1.3: Converting dd Image File to VHDX File



- While performing forensic examination on an image of a system drive, investigators might need to create a live environment of the machine to extract additional artifacts that may not be discovered in static analysis
- To do this, the investigator needs to boot the forensically acquired image file as a virtual machine

Step 1: Convert the acquired dd image file into a virtual machine file format using QEMU Disk Image Utility

- qemu-img is a command line tool used to create, convert, and modify image files offline
- Assuming Hyper-V to be the virtualization platform used for forensics, we shall convert the dd image to a vhdx file
- Use the following command to convert the dd image file to VHDX file

Command:

```
qemu-img convert -f <file format> <Source_Image_filename> -O vhdx <destination_filename.vhdx>
```


```
coot@jason-Virtual-Machine:/home/jason
root@jason-Virtual-Machine:/home/jason# qemu-img convert -f raw Evidence.dd -O v
hdx Evidence.vhdx
root@jason-Virtual-Machine:/home/jason# =
```



Scenario 1.3: Converting dd Image File to VHDX File (Cont'd)



Step 2: Create a new virtual machine by connecting the vhdx file and start it



VM is ready to Start

Step 3: Boot the virtual machine

- Now, the virtual machine boots from the forensic image file
- Upon successful login, the system runs in a live environment, allowing the investigator to perform live analysis



Live environment of the system

Scenario 1.4: Examining a dd Image File




Use the fdisk command to list information such as sector size, start sector, and type of evidence file

Step 1 Syntax: fdisk -1 <file_name>



The sector start point is required for calculating the offset value before mounting the image file



Scenario 1.4: Examining a dd Image File (Cont'd)



Step 2

Create a new directory to mount the image file

Syntax:

```
mkdir [options] directory_name(s)
```


If the mounted image contains multiple volumes, the user can mount one volume at a time by specifying an "offset" to the volume

Syntax:

```
mount -t ntfs -o ro, offset=[value_in_bytes]
[dd_image_file_name] [mount_directory]
```

- Run the 1s -1 command to navigate to the mount point directory and view the files/folders in the mounted volume
- Now, unmount the volume and calculate the MD5 hash of the image file and compare it with the computed MD5 hash value of the image file before it was mounted

```
root@jason-Virtual-Machine:/home/jason
root@jason-Virtual-Machine:/home/jason# mkdir Evidence 801
root@jason-Virtual-Machine:/home/jason#
```






Scenario 1.5: Examining Physical Hard Disk



Step 1: Determine the file system type

- Run the 1shw command in the command line terminal to view the attached hard disk and file system used in it
- gain "Ishw" is a command-line utility that lists detailed information about various hardware devices available on the machine

Note: Running the "Ishw" command without any "options" generates information about all detected hardware on the machine



Scenario 1.5: Examining Physical Hard Disk (Cont'd)



Step 2: List the partitions available on the evidence hard disk

 The isblk command lists information about all blocked devices connected to the system



Note: Use write blockers before connecting the physical hard disk to the Linux forensic workstation

Step 3: Mount the Windows file system on Linux using "mount" command

 Command: mount -t ntfs-3g -o ro [partition_number] [mount_directory]




 Mount Command, 2. Mounted Volume in read-only mode, 3. Files/Folders present in the Mounted Volume

Scenario 1.5: Examining Physical Hard Disk (Cont'd)



After the partition is mounted, the MOUNTPOINT for the partition is updated to /media/windows







Scenario 1.6: Examining Mac APFS Image File



- When the acquired evidence contains APFS and the forensic workstation is Linux, an investigator can use either mount, losetup, (mount and losetup) together, or (apfs-fuse) or (apfs-fuse and losetup) together to mount the image and view its contents
- In this scenario, we shall be mounting the evidence using losetup and apfs-fuse together

Step 1: Identify Unused Loopback Device

- To mount an image, first identify the unused loopback device
- Accordingly, issue the following command:

```
losetup -f
```

■ □ root@jason-Virtual-Machine:/home/jason root@jason-Virtual-Machine:/home/jason# losetup -f /dev/loop0 root@jason-Virtual-Machine:/home/jason#

Step 2: Mount the Image File onto the Unused Loopback Device

Now, mount the APFS image file to the unused loopback device using the following command:

```
losetup -r /dev/loop[number]
[evidence.dd]
```

```
© □ root@jason-Virtual-Machine:/home/jason
root@jason-Virtual-Machine:/home/jason# losetup -r /dev/loop@ apfs.dd
root@jason-Virtual-Machine:/home/jason#
```

Note: Here, /dev/loop17 is the unused loopback device, which might vary from one system to another

This creates a mount point on the machine. You may either view the image contents through the mount point or further mount this loop device using mount or apfs-fuse

Scenario 1.6: Examining Mac APFS Image File (Cont'd)



Step 3: Mount the APFS

Create a mount directory (named apfs) and mount the APFS on it using the following command:

```
mkdir /mnt/apfs
```

Mount the APFS onto the loopback device by issuing the following command:

```
mount /dev/loop[number] /mnt/apfs
(or)
```

```
apfs-fuse /dev/loop[number] /mnt/apfs
```

- If no error is generated, the image file is considered successfully mounted
- Upon successfully mounting the file system, you can view the contents of the image file as shown in the screenshot

```
root@james-Virtual-Nachine:/home/james# losetup -r /dev/loopt2 apfs.6d
root@james-Virtual-Nachine:/home/james# raidir /mnt/apfs|
root@james-Virtual-Nachine:/home/james# raidir /mnt/apfs|
mount:/mnt/apfs: waxming: source write-profested, nounted read-only-
root@james-Virtual-Nachine:/home/james# #
```




Scenario 1.7: Examining Disk Image Using PyTSK



- PyTSK is a Python wrapper for SleuthKit that provides a Python-based interface to access the libraries of SleuthKit using various Python scripts for performing different analysis tasks during an investigation
- You can use disk_analysis.py, a Python script available in Module 06 of your CHFlv11
 Student Resource Kit to access a disk image and view the associated files and directories






Scenario 2: Examining Images on Windows Forensic Workstation C HF



Tools such as Autopsy, FTK Imager, and Volatility enable investigators to examine image files on Windows forensic workstations and identify other files and folders located on them

Steps to View an Image File Using the Autopsy Tool

- Click on the "Add Data Source" option; then, select the required type of data source to add and click on "Next"
- Provide the path of data source to be examined
- Select the required modules as per the investigation and click on "Next"
- After module selection, click on the "Finish" button



Scenario 2: Examining Images on Windows Forensic Workstation (Cont'd)




Examining Mac HFS+ Image File

Method 1: Using Apple HFS+ Drivers Investigators can read Mac HFS+ through the Windows built-in File Explorer utility by installing Apple HFS+ Drivers on a Windows workstation that can provide insights about stored caches, saved files, etc. during an investigation

Steps to Read Mac HFS+ Using Apple HFS+ Driver

- Step 1: Install and extract the Apple HFS+ Windows driver package zip file on the Windows workstation
- Step 2: From the extracted folder, copy AppleHFS.sys and AppleMNT.sys files to C:Windows/System32/drivers/
- Step 3: Double-click on Add AppleHFS.reg in the extracted folder to merge the Apple HFS registry with the Windows registry. Next, Click on Yes and OK on the prompt window and restart the system



Scenario 2: Examining Images on Windows Forensic Workstation (Cont'd)




Examining Mac HFS+ Image File

Method 2: Using Paragon HFS+ for Windows





This tool helps to access HFS+ formatted drives collected from the evidence Mac system





Scenario 3: Examining Images on Mac Forensic Workstation




Tools such as R-Studio, Digital Collector, and OSForensics can help forensic investigators to examine image files on macOS forensic workstations and identify files and folders located in them

R-Studio

- R-Studio is a data recovery solution for recovering files from HFS/HFS+ and APFS (macOS) partitions along with Windows and Linux
- Investigators can use R-Studio to recover, view, and examine data from an image file





Digital Forensic Imaging Tools



OSFClone is a self-booting solution that allows investigators to OSFClone | create or clone exact raw disk images rapidly and independently of the installed OS





Module Summary



☐ In this module, we discussed various data acquisition methods, types, and formats ☐ This module explained the acquisition of volatile and non-volatile information from different OSes ☐ It also elaborated on the various steps involved in the data acquisition methodology ☐ Furthermore, this module discussed various possible scenarios that one might encounter while preparing an acquired image file for forensic examination ☐ Finally, this module concluded with an illustration on various digital forensic imaging tools ☐ In the next module, we will discuss how to defeat anti-forensic techniques in detail